



SHORTCUTS

SOME OF THE MORE COMMONLY USED SETTINGS/OPTIONS CAN BE ACCESSED QUICKLY WITH A SINGLE SWIPE; BELOW DETAILS HOW.

STEP 1:

PLACE YOUR FINGER SLIGHTLY **BELOW** THE SCREEN (TOUCHING THE IPAD CASING), THEN SWIPE UP A LITTLE. YOU WILL THEN SEE A NEW WINDOW POP UP.



Note: IN SOME CASES, DEPENDENT ON WHAT IS ON THE SCREEN AT THE TIME, YOU MAY SEE A 'TAB' APPEAR ON THE FIRST SWIPE . JUST HOLD THIS AND SWIPE UP AGAIN IN ORDER FOR THE WINDOW TO APPEAR.

STEP 2:

THE FOLLOWING DETAILS WHAT OPTIONS ARE AVAILABLE TO YOU




MUSIC CONTROLS:

PLAY AND SELECT TRACKS STORED ON THE IPAD



VOLUME CONTROLS:

ADJUST THE SLIDER TO INCREASE/DECREASE THE VOLUME LEVEL



SCREEN BRIGHTNESS:

ADJUST THE SLIDER TO INCREASE/DECREASE THE SCREEN BRIGHTNESS

SHORTCUTS

SOME OF THE MORE COMMONLY USED SETTINGS/OPTIONS CAN BE ACCESSED QUICKLY WITH A SINGLE SWIPE; BELOW DETAILS HOW.



TIMER AND CAMERA SHORTCUTS:

THE FIRST OPTION IS FOR THE TIMER/CLOCK/ALARM AND STOPWATCH. THE SECOND IS FOR THE CAMERA/VIDEO FEATURES



MISCELLANEOUS SHORTCUTS:

AIRPLANE MODE ON/OFF, WI-FI ON/OFF, BLUETOOTH ON/OFF, DO NOT DISTURB ON/OFF, LOCK SCREEN ROTATION ON/OFF

STEP 3:

TO CLOSE THE WINDOW TOUCH ON THE LITTLE DOWNWARD FACING ARROW (TOP MIDDLE)

